



SECURITY SOLUTIONS

ALARM SYSTEM USER GUIDE

How to arm and disarm the system

To fully arm the system, push the locked padlock, an audible delay time will begin giving you 30 seconds to exit.

To fully disarm the system, push the unlocked padlock and enter your user code.



To part arm the system, push the home button, a silent delay time will begin giving you 30 seconds to exit the part set area.

How to arm and disarm the system with a key fob

To part arm the system, push the home button, a silent delay time will begin giving you 30 seconds to exit the part set areas.

To fully arm the system, push the locked padlock, an audible delay time will begin giving you 30 seconds to exit. You can do this from inside the property or from outside the property



To fully disarm the system, push the unlocked padlock. You can do this from inside the property or from outside the property

Audible panic button

By pushing and holding both the locked and home button at the same time, this will activate the panic alarm

For audible status updates, push the star button. Please note, this only works for certain panels.

Keypads



To fully arm the system, push the locked padlock and enter your user code.

To part arm the system, push the home button, and enter your user code.

To fully disarm the system, push the unlocked padlock and enter your user code.

To fully arm the system, push the locked padlock and enter your user code.

To part arm the system, push the home button, and enter your user code.

To fully disarm the system, push the unlocked padlock and enter your user code.



To fully arm the system, push the locked padlock and enter your user code.

To part arm the system, push the home button, and enter your user code.

To fully disarm the system, push the unlocked padlock and enter your user code.



Useful operations



To change the time

Push the **scroll button** to “user settings” push the **OK button** and enter your user code. Push the **scroll button** to change time, push the **OK button**, enter the correct time, and push the **OK button** twice, once done, push the **locked padlock** and then push the **OK button**.

To change the user code

Push the **scroll button** to “user settings” push the **OK button** and enter your user code. Push the **scroll button** to user codes then push the **OK button**, push the **OK button** on user code 1 and enter your desired code, once done, push the **OK button** once more. Push the **locked padlock** symbol the push the **OK button**.

To change the date

Push the **scroll button** to “user settings” push the **OK button** and enter your user code. Push the **scroll button** to change date, push the **OK button**, enter the correct date, and push the **OK button** twice, once done, push the **locked padlock** and then push the **OK button**.

Devices available for your system

Intrusion Detectors



Outdoor PIR Motion Mirror Detector and Integrated Camera
TOWER CAM PG2



Outdoor PIR Motion Mirror Detector
TOWER-20AM PG2



Vanishing Contact
MC-302V PG2



Magnetic Contact
MC-302/E PG2



Shock Detector
SD-304 PG2



Curtain PIR Detector
Clip PG2



Motion Detector
Next PG2 / Next K9 PG2



Motion Detector with Anti-masking
TOWER-30AM PG2



Mirror Dual Technology Detector
TOWER-32AM PG2



Motion Detector with Integrated Camera
Next CAM PG2 / Next CAM K9 PG2



Glass Break Detector
GB-502 PG2



Gas Detector
GSD-441 PG2



Carbon Monoxide (CO) Detector
GSD-442 PG2



Smoke Detector
SMD-426 PG2



Smoke & Heat Detector
SMD-427 PG2



Flood Detector
FLD-550 PG2 / FLD-551 PG2



Temperature Detector
TMD-560 PG2

Safety Detectors



PowerMaster-33 G2
Distributed wireless alarm



PowerMaster-30 G2
64-zone control panel



PowerMaster-10 G2
30-zone control panel



Two-way Keypad
KP-250 PG2



Touch-screen Keypad
KP-160 PG2



Wireless Portable Keypad
KP-140 / 141 PG2



Proximity Tags Chicklets

Keypads



Slim Keyfob
KF-235 PG2



Keyfob
KF-234 PG2



Panic Button
PB-101 PG2



Panic Button
PB-102 PG2

Keyfobs



Panic Buttons



Alarm Communication



IP Security Management Platform
PowerManage



GSM/GPRS Communicator
GSM-350



IP Module
PowerLink3



3G Communicator
WCDMA-3G

Repeater



Repeater
RP-600 PG2



Indoor Siren
SR-720B PG2



Outdoor Siren
SR-740 PG2



Outdoor Siren
SR-740 HEX PG2

Sirens

